We at UNITEMP hope that you would take this opportunity to contact us.

Let us show you how PEKUTHERM® can purge and clean your thermoplastic machines.

Learn more on our website:





ADVANCED CONCEPTS IN THERMOPLASTICS MOLDING

1043 E. JOHN BEERS RD. • ST. JOSEPH, MI 49085PHONE: (269) 408-0280 • FAX: (269) 408-0281

EMAIL: pekutherm@gmail.com

www.pekutherm.org

"Savings in man hours and machine time (approx. 3 to 3.5 hrs.) - \$1,080 to \$1,254 per color change" - East Coast Molder

Notes:			

"Easy to handle, precisely measurable results, clearly visible purging effect."
- Tier 1 Molder, Germany



ADVANCED CONCEPTS IN THERMOPLASTICS MOLDING

1043 E. JOHN BEERS RD. • ST. JOSEPH, MI 49085 PHONE: (269) 408-0280 • FAX: (269) 408-0281

EMAIL: pekutherm@gmail.com

www.pekutherm.org

# **PEKUHERM**®

Black PC to Clear PC
in 5 mins

... "I've been in the business, my family's business, for 25 years. My father and I have tried everything. But I've never come across anything that does the job as well as this." - Midwest Molder

\*\*\*See inside for the actual field case.



THE THERMO-ELASTIC PURGE



#### \*\*\* continued from front cover:

• Type of Machine: Arburg 40 Ton (2.3 oz.)

PekuTherm® Formulation: "HLT"
Outgoing Material: PC "Black"
Incoming Material: PC "Clear"

Temperature: 500° F

Amount of PekuTherm®: 2 plugs @ 1 oz.

Amount of Contaminated Material: 8 oz.

Total Purge Time - Black to Clear: 5 mins

## Why PEKUTHERM® is different:

- Large working range (300° 752° F).
- Very short purge time needed. Can usually be into "sellable" parts in under 15 minutes.
- Compatible with all thermoplastic materials within the large working range.
- Does not wear on screw or barrel.
- No chemical reactions
- Soft-scouring self adhering plug.
- No soaking time needed.
- Loosens and removes carbon and gas residues.
- No acrylic residues left, works on clear materials.
- No contaminating carrier resin. Needs no premixing.(\*TI2 does use a carrier resin)

## What PEKUTHERM® has proven:

- Flexible compound (Large working range and various granulation sizes).
- Minimal purge and clearing time.
- No need to run excess incoming material to check purge purity levels because PEKUTHERM® shows you whether the machine is clean or not.
- **32 years** of proven success in the North American market.
- **36 years** of proven success in the European market.

### **PEKUTHERM® Formulations:**

- PekuTherm HLT Wide temperature range formula for all Injection presses.
- PekuTherm N Course granulate for Injection presses of 150 tons and greater
- PekuTherm SM Medium granulate for Injection presses of 80 tons - 150 tons
- PekuTherm SK Fine granulate for Injection presses of 80 tons and less.
- PekuTherm **EX** Extrusion Formula
- PekuTherm TI2 Hot Runner Formula

#### **Case Results:**

Type of Machine: Van Dorn 150 Ton (8 oz.)
 PekuTherm® Formulation: "N"

Outgoing Material: sp21 Nylon Orange Incoming Material: R543 Nylon (43% GF) Blue

Temperature: 500° F

Amount of PEKUTHERM "N": **2 plugs @ 5 oz.** Amount of Contaminated Material: **32 oz.** 

Total Purge Time - Black to Clear: 7 mins

• Type of Machine: Newberry 100 Ton (5 oz.)

PekuTherm® Formulation: "SM"

Outgoing Material: Rynite (30% GF) Brown

Incoming Material: Rynite Natural

Temperature: 555° F

Amount of PEKUTHERM "SM": 2 plugs @ 2.5 oz.

Amount of Contaminated Material: 8 oz.

Total Purge Time - Black to Clear: 8 mins

• Type of Machine: Arburg 40 Ton (1 oz.)

PekuTherm® Formulation: "SK"

Outgoing Material: **DuPont Minion (35%) Black** Incoming Material: **DuPont Minion (35%) Natural** 

Temperature: 565° F

Amount of PEKUTHERM "SK": **2 plugs @ 1 oz.**Amount of Contaminated Material: **12 oz.** 

Total Purge Time - Black to Clear: 7 mins

• Type of Machine: Cincinnati 850 Ton (232 oz.)

Total Part Weight: 8.7 lbs.

Hot Runner: Incoe direct gate 4 drop manifold

PekuTherm® Formulation: "TI2"

Outgoing Material: ABS Bright Red
Incoming Material: ABS Bright Yellow

Temperature: 440° F

Amount of PEKUTHERM "TI2": 2 plugs @ 160 oz.

Total Purge Time - Black to Clear: **15 mins**